



NETORIOUS COVER

Netorious Cover

 **Material**
Recycled polyester
solution dye

 **Coating**
Water and dirt repellent
PVC coating

 **Weight product**
0.89 kg

 **Dimensions**
189.5 x 160 cm

 **Weight product + packaging**
1.09 kg

 **Dimensions packaging**
45.3 x 25.3 x 7.6 cm

 **Batch number**
In the carrying bag on a
white label

 **Washing instructions**

- Wash cover at handwash only
- Do not bleach
- Do not tumble dry
- Do not iron
- Do not dry clean

 **Features**

- The cover makes sure your Netorious stays clean and dry when it's not being used
- UV-resistant
- Lightweight
- Bird proof

 **Recommendations**
General user instructions:
This cover is intended for temporary storage of your Fatboy product and protects your product against short periods of rainfall, excess exposure to sunlight and dirt. These covers should not be used for periods longer than 3 to 4 weeks. Read instructions below for storage longer than 3 to 4 weeks. The cover is not reversible. The glossy side must always face inwards, towards the furniture. Make sure the furniture is cleaned and dry before use. After putting the cover over the furniture, lift the furniture slightly and tuck in the lower edge underneath to ensure that the cover stays firmly in place regardless of weather conditions. Make sure water can run off by tilting the furniture

slightly. Prevent puddles of water from forming on your cover. Regularly check no water, leaves or dirt remains onto the cover; and ensure enough tensions is on the Cover by pulling the string tightly. Regularly check your product and allow air to ventilate, to avoid moisture, mildew and mould between the cover and product.

Long terms storage:
Long term exposure to wet weather conditions can damage your product and moisture, mildew and mould can develop on your product. Store your outdoor furniture, pillows and hammock in a cool dry place indoors during the off-season. To limit the development of moisture, cover your product and place it under a roof and on a dry and protected floor or surface. Regularly check your product and allow air to ventilate, to avoid moisture, mildew and mould between the cover and product.

HOW TO ENJOY YOUR PRODUCT TO THE MAX

Keeping it clean

To clean the cover from dust and dirt, spray it with cold water (30°C) from a garden hose or wipe it with a soft cloth soaked in water.

For heavily soiled areas, scrub with a sponge soaked in mild detergent and rinse with cold water.

WARNING

Keep all flame and heat sources away from this fabric

This fabric is not fireproof and will burn if left in continuous contact with a flame or any heat source

Not suitable for indoor use



Keeps your Netorious clean and dry

